



close-up on the control panel




Custom Imperial RCIB-645-2		Page
1	Surface Unit Signal Lights	9
2	Rear Surface Unit Controls	9
3	Meat Tender	26, 27
4	Oven Temperature Controls	20, 21
5	Broiler Grill Control	30, 31
6	Time Signal	below
7	Built-In Clock	9
8	Cook-Master Automatic Oven Controls	18, 19
9	Oven Signal Lights	20, 21
10	Heat-Minder Unit Control	9-11
11	Speed-Heat Unit Control	9-11
12	Light Switch	5




Electric Time Signal

Turn to time any cooking operation from 1 to 60 minutes. Buzzes gently but firmly when time is up until you turn it off.



Custom Imperial RCIB-635-2		Page
1	Surface Unit Signal Lights	9
2	Rear Surface Unit Controls	9
3	Meat Tender	26, 27
4	Oven Temperature Control	20, 21
5	Broiler Grill Control	30, 31
6	Time Signal	4
7	Built-In Clock	below
8	Cook-Master Automatic Oven Controls	18, 19
9	Light Switch	5
10	Oven Signal Lights	20, 21
11	Heat-Minder Unit Control	9-11
12	Speed-Heat Unit Control	9-11




Built-In Clock

To set hands of clock: turn white knob to the right.



Light Switch

Turn in either direction. At LAMP position, full-width fluorescent lamp lights cooking top. At OVEN & LAMP position, fluorescent lamp and oven lamp are lighted. At OVEN—ONLY oven is lighted. On 2-oven models, both oven lights operate from the same switch.



Appliance Outlet

Located at right above surface unit cover. Lets you plug in a coffee maker, toaster, other small appliances at range. For automatic control, by the "Cook-Master" see page 19.

Here is the "brain" of your new Frigidaire Flair Range—the easy-view Control Panel. The name of each control is listed below and with it the page number you'll want to check when you first use it.